

## Combination Keys:

Special Mode	Front Key Pressing (Interval 1 sec.)	Remark
Button Lock & Un-lock	"VOL-" → "VOL-" → "SETTING" → "HOME"	<ol style="list-style-type: none"> <li>1. Lock all buttons of front panel and RCU, except for "Power".</li> <li>2. All the SET functions should be workable via RS32, even the ones with according hot key in RCU like Mute,...etc.</li> </ol>
"MENU" Lock & Un-lock	"VOL+" → "VOL+" → "SETTING" → "HOME"	<ol style="list-style-type: none"> <li>1. Lock "MENU" key of front panel and RCU</li> <li>2. The Factory and Hospitality modes should not be blocked for the model using MENU-combined key to enter these two modes. Alternative approach will be indicated separately if any limitation by model.</li> </ol>
"POWER" Lock & Un-lock	"VOL-" → "VOL+" → "SETTING" → "HOME"	<ol style="list-style-type: none"> <li>1. Lock "POWER" key of front and RCU.</li> <li>2. The SET_POWER on/off should be workable via RS232, but does not mean. the POWER lock will be released under this case.</li> <li>3. Can not be un-locked by reset in OSD setting.</li> <li>4. Will auto AC power-on in power-lock.</li> <li>5. Under power-lock, the set will not enter power saving when no PC signal and neither not trun off when no other video signals after 15min.</li> </ol>
"Touch" Lock & Un-lock	"VOL+" → "VOL+" → "VOL+" → "SETTING" → "HOME"	Lock Touch moduel